

Xari Sport



mima®

Kg

Pesos - Medidas

lbs 29,50

kg 13,4



WEIGHT

chassis without wheels:	6,72 kg	14,81 lbs
chassis:	9,41 kg	20,75 lbs
chassis with seat:	13,40 kg	29,50 lbs

DIMENSIONS (LxW)

without folding: 79x62 cm 31,10"x24,41"

Plegado



Chasis plegado
con ruedas y asiento



DIMENSIONES (LxWxH)	TOTAL WEIGHT
97x60x63 cm	13,4
38,18"x23,3"x24,80"	29,50

Chasis plegado con
ruedas



DIMENSIONES (LxWxH)	TOTAL WEIGHT
71x42x62 cm	9,41
27,97"x16,53"x24,41"	20,75

Chasis plegado
sin ruedas



DIMENSIONES (LxWxH)	TOTAL WEIGHT
71x42x52 cm	6,72
27,93"x16,53"x20,47"	14,81



- **xari Sport** se puede plegar con el asiento en posición vertical mirando hacia fuera. (Nunca mirando a los papas)



- **xari Sport** no se puede plegar con la posición mirando a los padres o con el capazo puesto!



Que obtienes



Asiento Sport



Chasis Negro



Tapa cestila trasera



Tapa cestila delantera



Barra y fundas de barra/manillar en polipiel perforada



Capota extensible



Plastico de lluvia

Asiento reversible



1

Mirando a los papas



2

Descubriendo el mundo



3 posiciones de reclinado:



1 Sentado



2 Descansando



3 Durmiendo

Capota XL extensible canopy




xari Sport tiene una capota extensible con malla para dar mayor ventilacion y transpiracion.



Solapa



Capota extensible con malla para ventilacion.



ventana con tapa



Colores disponibles



Ebony
A411112



Charcoal
A411201

mima[®] xari sport

sport seat



Tambien esta disponible como accesorio para usuarios del clasico **mima xari** para prolongar la vida de su producto.

Que incluye?



Asiento y capota extensible.



Plastico de lluvia



Tapa cesta delantera.



Tapa cesta trasera.



Barra asiento
Funda barra + Funda manillar polipiel



mima® xari sport

xari sport CARRYCOT



xari Sport is suitable from birth thanks to the **xari Sport carrycot** (sold separately) that perfectly adapts to the **xari Sport** chassis, allowing baby to be comfortable and safe.
Available colours - Ebony



Que incluye



Cubrecapazo



Plastico capazo



Accesorios

Asiento (compatible con chasis xari)



AS411810



AS411201

Capazo xari sport



AS411112-01
(Ebony)

Mosquitera



S1101-04

Plastico lluvia



QS401-06

Adaptador grupo 0



G4104

Clip



G101-22X

Porta biberon/vasos



G102-21

Cojin reductor



S1101-04

Mantas



S1101-09BB2



S1101-09BG2

Parasoles




S1101-08BB2



S1101-08SW2

Care and maintenance



Cleaning the seat

The seat may be spot cleaned using a damp sponge with a mild soap or detergent. Allow to dry completely before folding or storing away.

If the canopy, accessories or seat become wrinkled or creased after the buggy has been folded for a long period of time, simply iron the fabric on the reverse side. Be sure to place a damp cloth between the iron and the fabric.

In some climates the covers and trims may be affected by mould and mildew. To help prevent this from occurring, store the product in a well ventilated area and refrain from folding.

Cleaning the chassis

Brush off excess dirt and remove sand and salt after visiting the beach; wipe clean with a moist cloth and mild cleaning agent.

Lubrication of moving parts

Periodically lubricate the wheels, the hinges and other sliding parts using light oil or silicon spray. Do not use heavy oil as this will attract dust and grit which tends to clog and damage moving parts.

i Follow these steps regularly in order to keep the buggy in perfect condition.

⚠ The fabrics and plastics are highly resistant, but excessive sun exposure can cause discolouring.

Guarantee



Your product adheres to current safety requirements and it is guaranteed to be in perfect condition at the time of purchase.


If this product shows signs of fabrication faults during the warranty period (after normal use and following the guidelines laid out in the user manual), please contact the seller.

Warranty conditions:

- The warranty period is 24 months from the date of purchase. This warranty period is not extendable, even in the event of repair.
- For the warranty to be valid you need to:
 1. Provide the original purchase receipt given to your retailer.
 2. Provide a description of the defect to your retailer.
- The warranty is made to the original owner of the product and is not transferable to any subsequent owner.
- The warranty provides a right to repair but does not permit exchanges or refunds.

The warranty does not apply in the following circumstances:

- The product has been modified or repaired by third parties.
- Corrosion or rust on the wheels and chassis due to extreme environmental conditions including high humidity, salt spray, ice or snow or due to insufficient care.
- The defect was caused by improper usage or maintenance or due to anything else deemed to be the fault of the user; in particular, failure to comply with the instructions for use as described in the user manual.
- The defect was caused as a result of an accident or airline/transport damage.
- Normal wear and tear that can be expected with daily use of this product.
- Discolouration or damage to the fabric due to washing, rainwater or excessive exposure to sunlight.
- The defect is the result of overloading (exceeding the maximum weight allowance for the child and any items being carried).



www.mimakids.com
info@mimakids.com

Please note that colours and contents may vary from those illustrated.
With reservations for misprint and change of product range.
Regarding mima accessories, always please check availability with your local retailer.
©Copyright 2020 mima International Ltd. All rights reserved.